




Unit : mm



Installation Manual:

- 1  The Ø25mm PVC tube for AC 220V or AC 110V Power wire (3 X Ø2.0mm).
- 2  The tube for RS485 wire (4 X Ø0.5mm) , TCP/IP wire (2X8 core) , Manually opening the turnstile wire (8 X Ø0.3mm) .
- 3  It is PCB board part .
- 4  Fixing the equipment with M12 X 90mm expansive bolt .