



Model: InBio 460 Pro Plus

- Operating System: Linux OS
- Number of Door: 4 Doors
- Card Capacity: 30,000 (default) and can be expanded up to 1,00,000 with a license
- Fingerprint Capacity: 20,000
- Transaction Capacity: 5, 00,000
- Communication: TCP/IP
- Numbers of readers Supported : 8 (8 RS-485 Reader or 4 26-bit wiegand reader)
- Types of readers Supported : 26-bit Wiegand and RS485 Readers
- Number of Inputs : 12 (4 Exit Device, 4 Door Status, 4 AUX Input)
- Number of Outputs :8 (4-Form C Relay or Lock and 4-Form C Relay for Aux Output)
- Mounting : Wall Mount
- Power Supply: 9.6V - 14.4V DC
- Operating Temperature: 0°C to 45°C
- Operating Humidity: 20% to 80% RH (Non-condensing)
- Dimensions (L * W * H): 226 mm*106 mm*36.07mm
- Access Control Interface: Wiegand (Card Reader/QR Code Reader) RS-485 (Card Reader)
- Communication: TCP/IP *1, RS-485*8, Wiegand*4,Aux Inputs *4, Aux Outputs *4, Lock*4, Door Sensor*4, Exit Button*4, Alarm*4

Supported Software And Database : eSSL BioCVsecurity 6.4.1 (Web Version) Database : Default PGSQL, Alternate : MSSQL / Oracle .

PC Requirements to Install Software : Your PC RAM should be 16GB RAM, OS should be windows 10 or above, Antivirus or Firewall should be off during the installation after the installation we can use.

Software Features : 256 Time Zones, 256 Access levels, Holidays, Anti-passback, Interlock function, Linkage function, Multi-Card Opening function, Remote door opening and closing, Advance Options, Global Anti-passback, Global Interlock, Multiple Verification Methods, Real-Time monitoring Via Web browser